Cover Rx assembly instructions

First inspect the included (2) hardware bags and all other parts (see figure 1) to make sure there is nothing missing

HARDWARE AND PARTS LIST:

А	@m-@-@-@	(2) of each - attaches main body to pivot arm tabs
В	(B) (C) (C) (C) (C) (C) (C) (C) (C) (C) (C	(2) total (B and C are identical) - connects to air shock (B is Pre-installed)
С	¢ •	
D		(2) Pins
Е	(tum (t)	(4) Screws + (2) Nuts - attaches baseplate to support legs
F	() ()	(2) of each - attaches main body to support legs

- G -(1)Gas Shock
- H (1) Base Plate
- I (2) Support Legs
- J (1) Pivot Arm
- K (1) Main Body
- L (2) Short U-Arm Elbows
- M (2) Long U-Arm Elbows
- N (2) U-Arm Spacers
- P (2) Bumper Knobs

Also includes all tools needed box wrench and allen wrench

Video instructions available at www.CoverValet.com



Figure 1 - Connection reference overview







Step 5 Slide U-Arms into pivot arm; align spring button so that it locks in place and insert pin all the way through hole and channel.



Attach the Ball stud with the lock nut to the tab on the right leg of the Main body. This ball stud should face the opposite direction as the pre-installed ball stud on the back of pivot arm.

Attach Gasshock to ball studs at C and B

Step 6

Step 7

Install bumper knobs into pivot arm*



- Step 8 Slide Sure lift (base Plate) under spa Leave 1/2" of space between the Sure Lift and your spa
- Step 9Tighten all screws and adjust height (F)The base of the U-arms should be flush with the top of the acrylic (see figure in step 7)
to ensure an easy slide in to the lifter.

